Appendix B – Best Management Practices

BMP SC06	OUTDOOR LOADING/UNLOADING OF MATERIALS	
	ce the discharge of pollutants to storm water from loading and aterial and cargo.	TARGETED ACTIVITIES: → Cargo Handling → Fuel Storage → Chemical Storage → Equipment Storage
POLLUTION PREVENTION:		
	Implement the following pollution prevention practices and BMPs to prevent non-storm water discharges of pollutants from outdoor loading and unloading of materials to the storm water collection system:	POLLUTANTS of CONCERN: → Fuel → Pesticides/Herbicides/Fertilizers → Oil and Grease → Solvents/Cleaning Solutions
	Transfer materials in paved areas, away from storm drain inlets.	→ Battery Acid
	Contain and absorb leaks during transfers and spillage from hose disconnections; dispose of residue properly.	
	Notify Airport Operations (619-400-2710) and the Airport Authority Planning & Environmental Affairs Department (619-400-2784) if any evidence of illegal discharges from outdoor material loading and unloading is observed.	
OPERATIONS	5:	APPLICABLE TENANTS/
Sub-BMPs		DEPARTMENTS:
- 01	Contractors and haulers should be made aware of and adhere to BMPs specifications that are relevant to the loading and unloading of materials.	→ Air Canada→ Alaska→ Allegiant
- 02 🗌	Loading and unloading areas should not be located directly in the path of storm drains.	→ American Airlines→ Bradford→ British Airways
- 03 🗌	Loading and unloading areas should be graded, bermed, covered or otherwise protected to prevent contact with rainfall and storm water run-on and runoff.	→ Conrac → Delta → DHL → FedEx
- 04 🗌	Equipment used for loading and unloading should be checked on a regular basis for leaks.	→ Flagship→ Frontier→ Hawaiian
- 05 🗌	Use drip pans or other containment measures under hoses.	→ HFF → HMS Host
- 06	Keep loading and unloading areas free of spills and debris by containing and absorbing leaks during transfers and spillage from hose disconnections or cargo pallets; dispose of residue or debris properly.	 → JAL → JetBlue → Lufthansa → Menzies → Menzies Fuel Farm
- 07 🗌	Spill kits or other measures are available in accessible locations near areas where spills may be likely to occur to contain spills and/or prevent tracking off-site.	 → Mission Yogurt → SANCO → SDCRAA → Signature → Southwest → Spirit

Appendix B – Best Management Practices

BMP SC06	OUTDOOR LOADING/UNLOADING OF MATERIALS	
		→ SSP → Sun Country → Swoop Airlines → United → UPS → WestJet
STRUCTURAL TREATMENT BMPs: Refer to BMP TC01 for information on structural treatment BMPs.		
BMP FREQUENCIES/EQUIPMENT/TOOLS: Loading/unloading is conducted as on a daily basis. Equipment/tools to implement BMPs include capture devices, drip pans, spill kits, brooms, and drums.		
AUTHORIZED LOCATIONS FOR THE OUTDOOR LOADING AND UNLOADING OF SIGNIFICANT MATERIALS:		
	Use only the designated areas for outdoor loading and unloading of significant materials as shown in the attached map.	
Date:		Version: 2.0

Appendix B - Best Management Practices

Intentionally Left Blank

