Appendix B – Best Management Practices

BMP SC08	WASTE HANDLING AND DISPOSAL		
PURPOSE: Prevent or reduce the discharge of pollutants to storm water from waste handling, storage and disposal by through source reduction, re-use, and recycling; and preventing run-on and runoff from waste management areas, including waste/garbage collection areas.		TAI + + + +	RGETED ACTIVITIES: Fuel/Chemical/Oil Waste Storage Painting/Stripping Waste/Garbage Collection
POLLUTION	PREVENTION:		
П	Implement the following pollution prevention practices and BMPs to prevent discharges of pollutants from waste handling, storage and disposal to the storm water collection system:	+ + +	Oil and Grease Paints Solvents/Cleaning Solutions
	Inspect on a regular basis waste/garbage collection area for spills and waste/garbage management containers for leaks.	→	Trash and Debris Vehicle Fluids
	Enclose or berm waste/garbage storage areas, if possible, to prevent contact with storm water run-on and run-off.		
	Place adequate spill kits in appropriate locations.		
	Engage in waste reduction programs (e.g. recycling and food waste composting). Investigate new processes and techniques to turn waste into a resource for others in order to reduce the impact people have on the environment.		
OPERATIONS	Ş.	A DI	PLICABLE TENANTS/
OI EKATION.	·•		PARTMENTS:
Sub-BMPs	·-		PARTMENTS:
	Reduce the amount of waste generated (e.g., use only amount	DEI	PARTMENTS: ABM
Sub-BMPs_	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory	DEI	PARTMENTS: ABM ACE
Sub-BMPs_	Reduce the amount of waste generated (e.g., use only amount	DEI ナ ナ	ABM ACE Air Canada
Sub-BMPs - 01	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.).	DEI	PARTMENTS: ABM ACE Air Canada Alaska
Sub-BMPs_	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory	DEI	ABM ACE Air Canada Alaska Allegiant
Sub-BMPs - 01	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.).	DEI	PARTMENTS: ABM ACE Air Canada Alaska
Sub-BMPs - 01 ☐ - 02 ☐ - 03 ☐	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access.	DEI + + + + + + + + + + + + + + + + + + +	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford
Sub-BMPs - 01 ☐ - 02 ☐	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm	DEI	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways
Sub-BMPs - 01 ☐ - 02 ☐ - 03 ☐	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access.	DEI ナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright
Sub-BMPs - 01 ☐ - 02 ☐ - 03 ☐	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm	DEI	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes.	DEI ナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta
Sub-BMPs - 01 ☐ - 02 ☐ - 03 ☐ - 04 ☐	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from	DEI ナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes.	DEI ナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes	DEI ナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □ - 06 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms.	DEI ナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian
Sub-BMPs - 01 - 02 - 03 - 04 - 05 - 06 - 07 - 07	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes plugged.	DEI ナナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian HFF
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □ - 06 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes plugged. Inspect on a frequent basis all waste collection and storage	DEI ナナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian HFF HMS Host
Sub-BMPs - 01 - 02 - 03 - 04 - 05 - 06 - 07 - 07	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes plugged. Inspect on a frequent basis all waste collection and storage containers for evidence of leaks, spills, compromised structural	DE ナナナナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian HFF HMS Host JAL
Sub-BMPs - 01 □ - 02 □ - 03 □ - 04 □ - 05 □ - 06 □ - 07 □ - 08 □	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes plugged. Inspect on a frequent basis all waste collection and storage	DEI ナナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian HFF HMS Host JAL JetBlue
Sub-BMPs - 01 - 02 - 03 - 04 - 05 - 06 - 07 - 07	Reduce the amount of waste generated (e.g., use only amount needed, use solvents more than once, practice good inventory control, do not over-buying, purchase long-lasting products, etc.). Recycle materials whenever possible. Designate waste/recycling areas with restrict access. Do not locate waste/recycling areas directly in the path of storm drains. Provide secondary containment and cover for wastes. Wastes that are not contained or covered are prevented from contacting storm water and run-on and run-off by the use of berms. All dumpsters are covered and kept closed and any drain holes plugged. Inspect on a frequent basis all waste collection and storage containers for evidence of leaks, spills, compromised structural	DE ナナナナナナナナナナナナナナナナナ	ABM ACE Air Canada Alaska Allegiant American Airlines ARFF Bradford British Airways Cartwright Conrac Delta DHL FedEx Flagship Frontier Hawaiian HFF HMS Host JAL

Appendix B – Best Management Practices

BMP SC08	WASTE HANDLING AND DISPOSAL	
- 10	Store wastes and recyclable materials in appropriate containers and segregate and properly labeled them.	 → Menzies Fuel Farm → Mission Yogurt → Port of San Diego
- 11 🗌	Wastes are properly characterized and disposed.	→ SANCO → SDCRAA
- 12	Prevent overflow of waste containers by timely pickup/service and removal. Perform dumpster cleaning in designated areas that are bermed to contain wash water. Properly dispose of all fluids collected or discharge to the sanitary sewer. Track waste generated, stored, and disposed.	 → Siemens → Signature → Southwest → SP Plus → Spirit → SSP → Sun Country → Swoop Airlines → United → UPS → WestJet
STRUCTURA structural treatm	L TREATMENT BMPs: Refer to BMP TC01 for information on nent BMPs.	
occurs on a dail outdoor sheds, o underground tar kits, brooms, an	ENCIES/EQUIPMENT/TOOLS: Waste handling and disposal y basis. Equipment/tools to implement BMPs include spill pallets, overpack containers, tarps, bermed or containment areas, sumps and aks, wooden pallets, covered dumpsters, covered storage areas, spill d drums. D LOCATIONS FOR WASTE HANDLING AND DISPOSAL: Conduct waste handling and disposal activities in the designated areas as shown in the attached map.	
Date:		Version: 2.0

Appendix B - Best Management Practices

Intentionally Left Blank

