

SAN DIEGO COUNTY REGIONAL AIRPORT AUTHORITY

CODES

ARTICLE 8 - GENERAL OPERATIONS
PART 8.1 - AIRCRAFT
SECTION 8.10 - AIRCRAFT OPERATIONS

(a) Federal Aviation Regulations pertaining to aircraft operations shall be observed at all times.

(b) No person shall perform any engine run up at a power setting above idle power between 11:30 p.m. and 6:30 a.m. (2330 - 0630 hours) (local time) at the Airport.

(c) Practice instrument approaches and touch and go landings are prohibited at the Airport.

(d) No aircraft shall be parked, stored or repaired on any airport under the jurisdiction of the Authority except in an area designated for such use.

(e) At the direction of the President/CEO or his or her designee, the operator, owner or pilot of any aircraft on any airport under the jurisdiction of the Authority shall move the aircraft from the place where it is parked or stored to any other place designated on the airport. In event of the failure or refusal to comply with such directions, the Authority may cause the aircraft to be moved to such place at the operator's expense and without liability for damage that may result from such moving.

(f) The owner of an aircraft, or part thereof, that is disabled on any airport under the jurisdiction of the Authority shall have it promptly removed to an area designated by the President/CEO, unless he or she is required to delay it pending investigation of an accident. In the event such aircraft, or part thereof, is not removed as directed by the President/CEO, the Authority may remove it at the owner's expense and without liability for additional damage resulting from the removal.

(g) No person may run an engine, or taxi an aircraft on the airport under the jurisdiction of the Authority in a manner that endangers any person or property or so as to compromise or diminish the safety of operations on such airport.

(h) The pilot of an aircraft involved in an accident on any airport under the jurisdiction of the Authority causing personal injury or property damage shall report in writing the accident fully to the President/CEO within 24 hours of such accident. In the event that he or she is unable to do so, the owner or his or her agent and any witnesses shall make such report.

(i) Airport property that is damaged or destroyed by an accident or otherwise shall be paid for by parties responsible therefor.

(j) No aircraft shall be taxied into or out of any hangar.

(k) The President/CEO shall have the authority to detain any aircraft for nonpayment of any charges due the Authority, or for the violation of any codes, rules or regulations of the Authority contained herein.

(l) No person shall park or stand an aircraft or load or unload aircraft passengers or cargo at any airport under the jurisdiction of the Authority except at such locations as may be permitted and approved by the President/CEO.

(m) No person shall use an air terminal building gate position at any airport under the jurisdiction of the Authority without permission from the President/CEO.

[Amended by Resolution No. 2019-0025 dated March 14, 2019.]
[Adopted by Resolution No. 2002-02 dated September 20, 2002.]